

Michem® Indicator 001

BRAND FAMILY OVERVIEW Primers explicitly designed for use on HP Indigo equipment with an in-line priming applicator to impart a print-receptive surface to most substrates, and improve the ink transfer and adhesion of HP Indigo ElectroInk.

USAGE Detects the presence of Michelman Primer treatments on dry coated substrates. When applied on dry surfaces which have been properly treated with Michelman Primer coatings, the indicator will change color from blue to yellow.

DESCRIPTION Indicator solution to detect the presence of acid functional primers.

PHYSICAL PROPERTIES The following properties are typical but should not be considered specifications:

Appearance:	blue liquid
pH:	12.0 - 13.8
Shelf Life (months) :	The product has a shelf life of 12 months from date of manufacture when storage and handling instructions are followed.

SITE OF MANUFACTURE (and PRODUCT CODE) USA (MI001), Belgium (MI001.E), Singapore (MI001.S)

APPLICATION DATA Apply a drop to the surface. The colour will change from blue to yellow if the surface has acid functionality.

STORAGE Keep away from open flames, hot surfaces and sources of ignition. Keep containers tightly closed in a dry, cool and well-ventilated place. Keep in a dry, cool and well-ventilated place. Keep in properly labeled containers. Keep tightly closed in a dry and cool place.

HANDLING Avoid breathing vapors or mists. Avoid contact with eyes, skin and clothing. Ensure adequate ventilation. Handle in accordance with good industrial hygiene and safety practice. Keep away from open flames, hot surfaces and sources of ignition. Take precautionary measures against static discharges. To avoid ignition of vapors by static electricity discharge, all metal parts of the equipment must be grounded. Use only in an area containing flame proof equipment. Use personal protective equipment as required.

Michem® Indicator 001

Revised 28 November 2022

The following information for this product, specific to each site of manufacture, is available upon request:

- Material Safety Data Sheets in various formats and languages (includes global chemical inventory listing)
- Food Contact Declaration of Compliance (if applicable)

Americas

Michelman Inc.
Tel: +1 513 793 7766
Fax: +1 513 793 2504

Luxembourg

Michelman International SARL
Tel: +352 26 39 44 1
Fax: +352 26 39 44 80

Singapore

Michelman Asia-Pacific Pte. Ltd.
Tel: +65 6861 2822
Fax: +65 6861 2262

China

Michelman New Material
(Shanghai) Co., Ltd.
Tel: +86 21 3810 3800
Fax: +86 21 3810 3811

India

Michelman Private Limited
Tel: +91 22 6221 3800
Fax: +91 22 6221 3801/02

The facts stated and the recommendations contained herein are based on our own research and the research of others, and are believed to be accurate. However, no guarantee of their accuracy is made because we cannot cover every possible application for our products nor anticipate every variation encountered in manufacturing equipment and methods. The products discussed are sold without warranty, express or implied and Seller disclaims any warranty of merchantability or fitness for a particular purpose in connection with the purchase of its products. It is recommended that purchasers conduct their own tests to determine the suitability of such products for their particular purpose. Seller shall not be liable for any injury, loss or damage, direct or consequential arising out of the use of or the inability to use the product. Statements concerning the possible use of our products are not intended as recommendations to use our products in the infringement of any patent and our products are sold without warranty of non-infringement.

© 2024 MICHELMAN, INC. All rights reserved. ® Reg. U.S. Pat. TM Off.

All marks contained herein are registered or owned by Michelman, Inc.

Michelman is ISO 9001:2015 certified.